

DUNKLEY

Scooter

MODEL S65

Operation & Maintenance

DUNKLEY

Scooter

MODEL S65

Operation & Maintenance

INTRODUCTION

Your Scooter, fitted with a Dunkley Motor OHV 4 Stroke Engine incorporating 2 speed gearbox, has been designed to give you many miles of trouble free riding with the minimum amount of attention. It is economical to run, simple to maintain in service. Every Scooter has been fully tested before leaving the Factory - it should, therefore, not be necessary to make any further adjustments. To obtain the best results the engine should be carefully run in for the first 500 miles. Speeds should not exceed:-

First Gear 17 Miles per hour

Top Gear 28 Miles per hour

Contents

	Page		Page
INTRODUCTION	3	MAINTENANCE	15
DATA	5	Oil Level	15
ON THE ROAD	8	Brakes	15
Petrol	8	Tyres	15
Controls	8	Tappet	16
Ignition & Lights	9	Spark Plug	17
Horn	9	Magneto	17
To Start The Engine	9	Decarbonize	18
Riding Technique	10	FAULT FINDING	20
Running in.	10	REPLACEMENT PARTS LIST	26
ADJUSTMENTS	12		
Gear Change	12		
Clutch Lever	12		
Clutch	12		
Slow Running	13		

Illustrations

Clutch & Gear Change	8	Adjustments & Maintenance	14
Ignition & Light Switch	9	Dipstick	15
Clutch	13	Cylinder Head	16

DATA

ENGINE	Four Stroke OHV. Bore 44 m/m. Stroke 42 m/m.
		Capacity 65 c.c. BHP. 2.6 at 5,200 R.P.M.
PISTON	Heplex split skirt, 1 compression ring,
		1 step compression ring, 1 oil control ring.
RING GAP004 - .010".
BEARINGS	Heavy duty ballrace. Roller big end.
LUBRICATION	Wet sump.
OIL	Recommended Oil:- Winter: SHELL X100-30.
		Summer: SHELL X100-40.
OIL CAPACITY	5/8 Pint.
TRANSMISSION	1/2" x 3/16" Heavy Duty Chain.
IGNITION	Flywheel magneto, incorporating lighting
		coil. Contact point gap .015".
SPARK PLUG	KLG F.50 Points Gap .022".
CARBURETTOR	Amal.
		Jet size 35.
		Throttle slide No. 2.
		Jet Needle Clip No. 2 position.
TYRES	Dunlop 2.50" x 15"
		Pressure:- Front: 22 lbs.
		Rear : 26 lbs. (34 with Pillion
		Passenger).
PETROL TANK	Capacity 8 Pints.

IMPORTANT WARNING

THE OIL SUMP LEVEL

MUST BE CHECKED

DAILY,



OR EVERY 100 MILES.

The body hinges up for maintenance of the engine and chassis and is lifted as follows:-

Move the locking bar at the rear of the saddle from left to right and hinge the saddle upwards, remove the two wing nuts securing the body and relock the saddle, now lift the body upwards from the rear end. Mounted on the front of the petrol tank is the body rest bar; turn this bar to a horizontal position and lower the body onto it.

When lowering the body back into position always check that the footbrake pedal has entered the socket on the brake arm.

See Page 14



ON THE ROAD

PETROL


Use **ONLY** premium grade petrol. Do NOT fill the tank with a petrol/Oil mixture. Your Scooter is fitted with a four stroke engine which runs on Pure Petrol and which has a separate oil sump.

CONTROLS

THROTTLE: Sitting on the saddle, on the right side of the handlebar is your throttle twist grip control. The lever attached to the twist grip operates the front brake.

CLUTCH & GEAR: On the left side of the handlebar is the twist grip gear control which is marked 1, zero and 2.

Position 1	-	Bottom gear.
"	Zero	- Neutral.
"	2	- Top Gear.



The clutch lever is attached to this control and gear change cannot move without first lifting the clutch lever.

LIGHTS, HORN AND IGNITION CUT OUT.

These are controlled from a switch mounted on the right side of the handle bar and operated as follows:-

LIGHTS: Lever in centre of switch. Fig. 2.

Lever Position:	Centre	-	off
	Left	-	dim
	Right	-	head


HORN: By button in centre of switch. Fig. 2.

CUT OUT: By button in right side of switch. Fig. 2.

TO START ENGINE: Turn on petrol, the petrol tap is in the ON position with the lever pointing in the direction of the petrol flow.

Your Dunkley Scooter is fitted with an Amal carburettor which has an auxiliary starting chamber for use when the engine is cold. This is brought into use by lifting the engine inspection door and pulling upwards the flexible rod protruding from the carburettor top.

Fig. 4. This rod should be held up for a maximum of two seconds only. If it is held up for a long period over richness will occur and cause difficult starting. It will not be necessary to use the starting chamber during the summer weather.



LIGHTS, HORN AND IGNITION CUT OUT.

These are controlled from a switch mounted on the right side of the handle bar and operated as follows:-

LIGHTS: Lever in centre of switch. Fig. 2.

Lever Position:	Centre	-	off
	Left	-	dim
	Right	-	head

HORN: By button in centre of switch. Fig. 2.

CUT OUT: By button in right side of switch. Fig. 2.

TO START ENGINE: Turn on petrol. the petrol tap is in the ON position.

Check that the gear change control is in the neutral position, then sharply depress the kickstart lever with the foot. When kicking the engine over the throttle should only be opened very slightly, if the throttle is fully open, the engine may be difficult to start.




Fig. 2

starting chamber during the summer weather.

TO DRIVE AWAY:

Sit on the saddle with the engine running, pull up the clutch lever and turn the control to position marked "1", now start to open the throttle and at the same time gently release the clutch lever; your Scooter will then move forward. After reaching a speed of 17 M.P.H. approx. change up to top gear No. 2 position.

TO SLOW DOWN OR STOP:

When you wish to travel at a low speed DO NOT try and do so by keeping the machine in top gear and slipping the clutch (this will cause undue strain and wear) always change to bottom gear for slow speed riding; when riding in traffic; up a steep hill etc. If you want to stop as at traffic controls etc., always pull up your clutch lever and turn the control to the neutral position and release the clutch lever. Then re-engage bottom gear when you are ready to move off. DO NOT wait with the clutch disengaged and the engine in gear as this causes undue wear to the clutch mechanism.

TO STOP THE ENGINE:

With the gear change control in the neutral position press the cut-out button in right side of switch case, see Fig. 2, turn off the petrol.

RUNNING IN:

Your Scooter will require running in for the first 500 miles, this means that whilst the engine is new it requires care in use. You should not travel longer than necessary in bottom gear as this causes over

heating. Always avoid over-running, but do not travel too slowly in top gear, always change down to low gear. For the first 500 miles the recommended speeds are 17 M.P.H. in low gear and 30 M.P.H. in top gear.

ADJUSTMENTS

GEAR CHANGE:

The adjuster for this is screwed into the gear change lever and is adjusted as follows:- Place the gear change control in the NEUTRAL position, the adjuster is then screwed in or out until the rear wheel spins perfectly free. If while travelling in bottom gear, the gear tends to disengage, this indicates that the cable adjuster should be gradually screwed out until bottom gear is positively engaged. If top gear disengages while riding, this indicates that the cable adjuster should be screwed in, also check that the inner wire of the cable is perfectly free and does not require oiling. After making any adjustment always ensure that the engine and rear wheel are perfectly free in the neutral position.

CLUTCH LEVER:


The movement of the clutch lever should be adjusted by means of the adjuster in the clutch cable so that there is 1/8" free play at the end of the lever.

CLUTCH:

There should always be a minimum of 1/8" free movement on the clutch lever attached to the spindle in the clutch housing, adjustment to this


carried out as follows:-

Remove the three screws securing the Clutch Housing and lift off; the clutch is now visible. In the centre of the clutch is the thrust rod, behind the head of this rod are one or two thin washers, if the movement on the end of the lever is too great, additional washers should be fitted (Part No:223) and a washer removed if there is insufficient movement. Always ensure that there is at least $1/8$ " movement at the end of the lever otherwise clutch slip will be experienced.



SLOW RUNNING:

This adjustment is carried out with the adjuster provided in the throttle control. The amount of petrol used by the engine can be varied by adjusting the height of the jet needle. This is carried out as follows:- Unscrew the mixing chamber top of the carburettor and withdraw the throttle valve assembly, then pull up the throttle valve spring and fully compress; the jet needle can be withdrawn from the throttle valve, the clip on the jet needle should be carefully removed and refitted to a higher groove to weaken the petrol mixture and a lower groove to richen. The normal position is the 2nd groove from the top.



Maintenance

DAILY


OIL LEVEL: The sump oil level should be checked by unscrewing the dip stick and removing from the crankcase, the dip stick should then be wiped and screwed back into the crankcase, then removed again and the oil level noted. The dip stick has two levels i.e. high and low, the oil level should at all times be kept at the high mark and never let fall below the LOW level. Use only recommended grades of oil.

BRAKES:

Always check that the brakes are in good order and working efficiently. Never leave adjusting the brakes until tomorrow - your life or someone else's may depend on them. The front brake adjuster is fitted in the brake cable close to the brake lever. The rear brake is adjusted by turning the knurled knob at the end of the brake rod.

TYRES:


Inspect tyres for cuts and remove any flints, etc. afterwards inflate to the correct pressure, front 22 lbs., rear 26 lbs.



FIRST 250 MILES

TAPPET ADJUSTMENT:

This should be carried out only when the engine is cold. Remove spark plug, flywheel cover and rocker box cover and check the cylinder head nuts for tightness, then proceed to adjust the tappets as follows:- Turn the magneto flywheel in an anti-clockwise direction until the inlet valve opens and closes again, continue turning until the piston is at top dead centre (that is until the piston is at the top of its stroke close to the cylinder head). In this position you can adjust both tappets. Slacken off the top adjusting screw locknut and then the bottom locknut, now with a screwdriver turn the adjusting screw until a .002" feeler will just slide between the valve cap and the rocker face. When the correct adjustment has been obtained the adjusting screw should be held in position with the screwdriver and the top locknut tightened first and then the bottom nut. (Remember always when retightening the tappet locknuts that the top nut must be tightened first). After tightening the locknuts recheck the clearance between the valve cap and rocker. Refit the rocker box cover making certain that the gasket is in position. It is safest to stick the gasket in position with grease or a little joining compound.



ENGINE OIL:

The engine oil should be drained whilst the engine is still warm after running. This is carried out by removing the drain plug at the bottom of the crankcase. After all the oil has been drained out replace the drain plug and refill the engine with $\frac{1}{2}$ pint of a recommended grade of oil.

SHELL X100-30 Winter

SHELL X100-40 Summer

SPARK PLUG:

Check spark plug points gap and reset to .022" to .025".

MAGNETO:

The magneto contact breaker points should be checked and if necessary reset. This adjustment is carried out as follows:- Turn the magneto flywheel in an anti-clockwise direction until the contact breaker points are visible through the inspection slot and are fully open adjacent to the word Bletchley. Slacken off the large locking screw immediately above the contact breaker points now turn the small adjusting screw in a clockwise direction to increase the points gap and anti-clockwise to reduce. The correct gap is .015" this should be checked with a feeler gauge. When the setting has been obtained retighten the locking screw and re-check the points gap. NOTE: Always make certain that the feeler gauge is perfectly clean before inserting between the contact breaker points. A dirty feeler gauge can cause burnt contact points, poor starting and erratic running.

CHAIN ADJUSTMENT:

Adjust rear chain by loosening wheel nuts and pulling wheel back with adjuster provided. Ensure wheel is in correct alignment and retighten wheel nuts.

EVERY 1,000 MILES

Drain engine oil as instructions for first 250 miles.

EVERY 3,000 MILES

DECARBONIZE:

Unscrew the nuts securing the valve rocker box and lift off the cover. Next remove the four nuts securing the cylinder head and carefully slide the cylinder head off the engine studs. (When lifting the cylinder head ensure that the push rods remain in position and do not lift with the cylinder head otherwise they may drop into the engine sump). Remove the cylinder head gasket; next with a screwdriver or similar instrument carefully scrape the carbon from the top of the piston. The carbon should then be scraped from the compression chamber of the cylinder head and the valves removed:- A convenient way to remove the valves is as follows:- Place a small block in the compression chamber of the cylinder head and put the cylinder head on the bench with the compression chambers downwards, then with a suitable tool, such as an open ended spanner, push downwards on the valve cotter plate, this will compress the valve spring and will allow the split cotters to be removed. Carefully release the tension on the valve spring and remove the valve spring and valve. Carefully keep the valves, springs, cotter plate and split cotters in sets and note whether they are from inlet or exhaust so that they can be fitted back in their correct ports in the cylinder head. The carbon should then

be scraped from the valve and valve ports and the surfaces polished with fine emery paper. Care should be taken when cleaning these parts that the valve seat faces are not scratched, otherwise it will take a considerable time to "lap in" the valve faces again.

To "lap in" the valves you require some coarse and fine Carborundum paste. First smear a small amount of coarse paste on the face of the valve, then insert the valve in its correct guide and with a screwdriver rotate the valve backwards and forwards; remove the valve and examine the seatings, these should be "matt grey" and free from all blemishes. When you are satisfied with the valve seatings, a small amount of fine paste should then be smeared on the valve seatings and the valve again "lapped in" until the seatings have a fine smooth matt finish. The valve and valve seating should then be washed in paraffin or petrol, the valves replaced in their correct guide, and the valves, spring, etc., refitted. Replace the cylinder head gasket and refit the cylinder head taking care to ensure that push rods enter the tappet adjusting screws. (It will be found that by pushing down on the rocker adjusting screws so that the rocker is at 45° to the cylinder head, the push rods will then readily enter the adjusting screws). Fully tighten the cylinder head nuts and adjust the tappet clearance as instructions for first 250 miles. Check magneto contact breaker points as instructions for first 250 miles.

If new piston rings are fitted the top ring should be replaced with the side of the ring marked TOP. nearest the crown of the piston. The stepped compression should be fitted with the cutaway section nearest the gudgeon pin.

FAULT FINDING

IF ENGINE WILL NOT START:

Check that petrol tap is in ON Position. Check that the ignition is switched ON.

Remove the spark plug and examine: if the plug is dry it indicates that there is something wrong with the petrol system. If the plug is wet with petrol it is an indication that the carburettor is flooding or that there is not a sufficiently strong spark at the plug to ignite the petrol.

CHECK PETROL SYSTEM

- (1) AIR VENT HOLE: Examine the air vent hole in the petrol filler cap.
- (2) CARBURETTOR: With the petrol tap off remove the nut from the base of the carburettor mixing chamber and allow the petrol to drain off, next turn on the petrol, the petrol should now flow through the carburettor and out past the jet - if the petrol drips very slowly or does not flow at all, this

indicates that the feed hole in the float chamber cover is choked. Remove the float chamber cover and clean the feed hole - when refitting making certain that the float needle enters its seating, and also that gasket is in position.

- (3) CLEAN JET: Remove the carburettor jet and examine - the hole in the jet is so small that it is not always possible to see an obstruction with the naked eye. It is, therefore, recommended that the jet is cleaned by passing a piece of soft copper wire, such as a fuse wire, through it; refit the jet and nut to the base of the carburettor.

CHECK IGNITION SYSTEM

- (1) PLUG: Remove spark plug from the engine, clean and adjust. Correct gap at points .022" to .025". Try new plug
- (2) MAGNETO CONTACT BREAKER POINTS: Check contact breaker points as for 250 miles.
- (3) SPARK: Remove the terminal from the end of the H.T. lead and the plug from the engine. Hold the end of the H.T. lead 3/16" to 1/4" away from the cylinder head, then rotate the engine with the pedals or kick start - the spark should then jump the gap of 3/16"; if it does not it indicates that the magneto is possibly faulty and should be examined

by a specialist. (Do not connect the H.T. to the plug and try the spark via the plugs. The gap on the plug is too small to give a true indication of the strength of the spark from the magneto).

- (4) H.T. LEAD: Examine the H.T. Lead for any cracks, etc., that will allow the spark to earth in damp or wet conditions. Do not join a new length on to your H.T. Lead, always fit a new one.

ENGINE DIFFICULT TO START

- (1) Check contact breaker points and plug gap as per maintenance instructions.
- (2) Check compression as instructions for "If engine lacks power" (1).
- (3) Check petrol system as per instructions "If engine will not start" (2) and (3).
- (4) Check inlet manifold screws for tightness; if necessary fit a new gasket.

IF ENGINE LACKS POWER

- (1) CHECK COMPRESSION: By rotating the flywheel in an anti-

clockwise direction. If compression is poor or non-existent examine tappet adjustment as per instructions for 250 miles. If tappet adjustment is correct the cylinder head should be removed and valves lapped in as instructions for decarbonizing at 3000 miles.

- (2) CARBURETTOR: Remove the carburettor from the inlet manifold and whilst looking through the rear aperture of the carburettor, open the throttle by rotating the twist grip and ascertain that the throttle valve is opening fully (i.e. leaving the hole in the carburettor completely unobstructed). If the throttle valve is not fully opening this should be adjusted by the cable adjuster fitted in the mixing chamber top.
- (3) Check petrol system as per instructions "If engine will not start" (2) and (3).

IF ENGINE IS ERRATIC

- (1) Check plug and contact breaker points as in maintenance instructions for first 250 miles.
- (2) Check for air leak in manifold or in "If engine difficult to start" (4).
- (3) Check spark as in "If engine will not start". Ignition system (3).

**ALWAYS QUOTE
ENGINE NO.
AND FRAME NO.
IN ALL
CORRESPONDENCE.**

REPLACEMENT PARTS LIST

<u>PART NO.</u>	<u>DESCRIPTION OF PARTS</u>	<u>PART NO.</u>	<u>DESCRIPTION OF PARTS.</u>
S65 - 123	Valve Rocker Cover.	S65 - 139	Valve Cotter Plate.
S65 - 124	Valve Rocker Cover Gasket.	S65 - 140	Valve Spring.
S65 - 125	Nut for 123.	S65 - 141	Valve Spring base plate.
S65 - 126	Washer for 125.	S65 - 142	Valve Guide.
S65 - 270	Oil Baffle.	S65 - 144	Spark Plug.
S65 - 125	Nut for 270.	S65 - 145	Spark Plug Gasket.
S65 - 126	Spacing washer for 270.	S65 - 146	Spark Plug Cover.
S65 - 127	Rocker Spindle.	S65 - 147	Inlet Manifold.
S65 - 128	Rocker.	S65 - 148	Inlet & Exhaust
S65 - 129	Rocker Spacing Washer.		Manifold Gasket.
S65 - 130	Tappet Adjusting Screw.	S65 - 149	Inlet Manifold Securing
S65 - 131	Locknut for 130.	S65 - 150	Washer for 149. (Screw.
S65 - 131N	Locknut Nyloc for 130.	S65 - 274	Cylinder Barrel.
S65 - 271	Cylinder Head Casting.	S65 - 152	Cylinder Barrel Gasket.
S65 - 272	Cylinder Head Gasket.	S65 - 275	Piston only.
S65 - 125	Cylinder Head Securing Nut.	S65 - 276	Piston Gudgeon Pin.
S65 - 134N	Cylinder Head Securing Nut Nyloc.	S65 - 155	Piston Gudgeon Pin Circlip.
S65 - 126	Washer for 125.	S65 - 277	Piston Compression Ring.
S65 - 273	Valve.	S65 - 278	Stepped Compression Ring.
S65 - 137	Valve Cap.	S65 - 279	Oil Control Ring.
S65 - 138	Valve Split Cotter.	S65 - 280	Engine Stud Long.
		S65 - 281	Engine Stud Short.

PART NO. DESCRIPTION OF PARTS.

S65 - 282 Push Rod.
S65 - 161 Cam Follower. Inlet.
S65 - 162 Cam Follower Exhaust.
S65 - 163 Cam Follower Spindle.
S65 - 164 Cam Follower Spacing Washer.
S65 - 165 Camshaft.
S65 - 166 Camshaft Bushes.
S65 - 167 Camshaft Spindle.
S65 - 168 Camshaft Spindle Circlip.
S65 - 169 Camshaft Spindle D Washer.
S65 - 170 Camshaft Spindle Securing Nut.
S65 - 171 Washer for 170.
S65 - 172 Crankshaft Gear.
S65 - 173 Crankshaft Gear Woodruff Key.
S65 - 174 Duplex Gear.
S65 - 175 Bush for 174.
S65 - 176 First Gear.
S65 - 283 Secondary Shaft.
S65 - 179 Secondary Shaft Circlip.
S65 - 180 Sliding Gear Selector.
S65 - 181 Gear Selector Fork.
S65 - 182 Gear Selector Fork Spring.
S65 - 183 Thrust Washer for 182.
S65 - 184 Gear Selector Fork Spindle.

PART NO. DESCRIPTION OF PARTS.

S65 - 185 "E" Clip for 184.
S65 - 186 Securing Nut for 184.
S65 - 187 Washer for 186.
S65 - 188 Gear Selector Cam & Spindle.
S65 - 189 "O" Sealing Ring for 188.
S65 - 190 Nut for 188.
S65 - 191 Washer for 190.
S65 - 192 Gear Change Lever.
S65 - 193 Crankshaft Assembly.
S65 - 195 Connecting Rod Small End Bush.
S65 - 284 Crankcase (sets only).
S65 - 199 Crankcase dowl pin.
S65 - 200 Crankcase Gasket.
S65 - 201 Crankcase Securing Screw Long.
S65 - 202 Crankcase Securing Screw Short.
S65 - 203 Crankcase Drain Plug.
S65 - 204 Crankcase Drain Plug Washer.
S65 - 285 Main Bearing (Magnetos Side).
S65 - 285 Main Bearing (Clutch Side).
S65 - 286 Bearing Secondary Shaft Thrust.
S65 - 285 Bearing Secondary Shaft.
S65 - 209 Oil Seal Main Bearing.
S65 - 287 Oil Seal Secondary Shaft.
S65 - 211 Oil Level Stick.

<u>PART NO.</u>	<u>DESCRIPTION OF PARTS.</u>	<u>PART NO.</u>	<u>DESCRIPTION OF PARTS.</u>
S65 - 212	Clutch Retainer/Chain Sprocket.	S65 - 236	Clutch Cover Oiler.
S65 - 213	Chain Sprocket Bush.	S65 - 237	Clutch Cover Securing Screw.
S65 - 216	Clutch Pressure Plate.	S65 - 240	Magneto Stator Plate Securing
S65 - 217	Clutch Centre Plate.	S65 - 241	Washer for 240. (Screw
S65 - 218	Clutch Drive Plate.	S65 - 245	Magneto Rotor Securing Nut.
S65 - 219	Clutch Spring Main.	S65 - 246	Washer for 245.
S65 - 214	Clutch Spring Internal.	S65 - 288	Kickstart Folding Arm.
S65 - 220	Clutch Spring Retaining Plate.	S65 - 289	Kickstart Crank.
S65 - 221	Locking Clip for 220.	S65 - 290	Bolt for 288.
S65 - 222	Clutch Thrust Rod.	S65 - 291	Spring for 289.
S65 - 223	Adjusting Washer for 222.	S65 - 292	Ball for 289.
S65 - 224	Clutch Thrust Rod Carrier Plate.	S65 - 293	Securing Bolt for 289.
S65 - 225	Clutch Thrust Lever.	S65 - 294	Nut for 293.
S65 - 226	Clutch Thrust Lever Ball.	S65 - 295	Washer for 294.
S65 - 227	Leaf Spring for 225.	S65 - 296	Kickstart Return Spring.
S65 - 228	Screw for 227.	S65 - 297	Pawl Carrier Shaft.
S65 - 229	Washer for 228.	S65 - 298	Pawl.
S65 - 230	Clutch Thrust Spindle.	S65 - 299	Pawl Plunger.
S65 - 231	"E" Clip for 230.	S65 - 300	Pawl Plunger Spring.
S65 - 232	Clutch Lever.	S65 - 301	Bush/Pawl Carrier Shaft.
S65 - 215	Clutch Lever Return Spring.	S65 - 302	"O" Sealing Ring.
S65 - 233	Nut for 232.	S65 - 303	"O" Sealing Ring. Circlip.
S65 - 234	Washer for 233.	S65 - 304	Kickstart Gear.
S65 - 235	Clutch Cover.	S65 - 305	Kickstart Distance Shaft.


PART NO. DESCRIPTION OF PARTS.

S65 - 306	Bush/Kickstart Distance Shaft.	S65 - 316	Crankcase Breather Banjo.
S65 - 307	Kickstart Stop Plate.	S65 - 317	Bolt for 315.
S65 - 308	Screw for 307.	S65 - 318	Washers for 316.
S65 - 309	Washer for 308.	S65 - 319	PVC. Tube for 315.
S65 - 251	Rear Engine Mounting Stud.		
S65 - 310	Rear Engine Mounting Rubber.		
S65 - 254	Rear Engine Mounting Rubber Spacer.		
S65 - 315	Engine Mounting Back Plate.		
S65 - 125	Nut for 251.		
S65 - 126	Washer for 125.		
S65 - 256	Top Engine Mounting Clip.		
S65 - 257	Top Engine Mounting Rubber.		
S65 - 258	Top Engine Mounting Bolt.		
S65 - 311	Nut for 258.		
S65 - 312	Washer for 311.		
S65 - 313	Name Plate.		
S65 - 314	Name Plate rivet.		

USE ONLY GENUINE DUNKLEY SPARES FOR RELIABLE SERVICE

Always quote Engine No. and Frame No. in all correspondence.

IceniCAM Information Service



www.icenicam.org.uk