


## Spare Parts List for TYPE Nos. 379 & 391 CARBURETTORS



**SPARE PARTS LIST FOR  
TYPE Nos. 379 and 391 STANDARD CARBURETTERS**

Component	379 Standard Carburettor	379 Standard Carburettor when fitted with Type 384/ Air Filter	391 Standard Carburettor	391 Standard Carburettor when fitted with Type 394/ Air Filter
	Part No.	Part No.	Part No.	Part No.
Tickler, complete .. .. .	—	—	352/233	352/233
Float Chamber Cover Screws ..	352/209	352/209	352/209	352/209
Float Chamber Cover, complete ..	379/003	379/003	391/033	391/033
Tickler Spring .. .. .	—	—	352/208	352/208
Tickler Spring Screw .. .. .	—	—	352/207	352/207
Float Chamber Cover Washer ..	379/004	379/004	—	—
Outlet Clamp Screw .. .. .	11/014	11/014	4/048	4/048
Cable Adjuster .. .. .	308/041	308/041	52/068	52/068
Cable Adjuster Locknut .. .. .	308/042	308/042	391/022	391/022
Mixing Chamber Top .. .. .	308/040	308/040	161/055	161/055
Throttle Valve Spring .. .. .	308/038	308/038	52/057	52/057
Jet Needle Clip .. .. .	308/044	308/044	161/054	161/054
Jet Needle .. .. .	308/043	308/043	223/017	223/017
Throttle Valve .. .. .	308/125	308/125	261/056	261/056
Float, complete .. .. .	308/022	308/022	124/036	124/036
Carburettor Body .. .. .	★	★	★	★
Needle Jet .. .. .	335/019	335/019	223/016	223/016
Main Jet .. .. .	124/026	124/026	4/042	4/042
Petrol Filter .. .. .	360/051	360/051	391/032	391/032
Jet Cover Washer .. .. .	38/023	38/023	391/019	391/019
Jet Cover .. .. .	360/020	360/020	391/012	391/012
Needle Seating Washer .. .. .	360/038	360/038	59/023	59/023
Needle Seating .. .. .	360/037	360/037	391/024	391/024
Banjo Top Washer .. .. .	—	—	391/026	391/026
Float Needle .. .. .	308/025	308/025	124/031	124/031
Banjo .. .. .	360/036	360/036	391/025	391/025
Banjo Bolt Washer .. .. .	360/040	360/040	376/092	376/092
Banjo Bolt .. .. .	360/039	360/039	376/091	376/091
Air Filter, complete .. .. .	—	384/1	—	394/1
Filter Plates .. .. .	360/030	—	391/018	—
Filter Gauze .. .. .	360/047	—	—	—
Shutter and Knob Assembly ..	362/023	383/008	391/020	394/019
Filter Cover .. .. .	362/022	362/022	391/010	391/010
Filter Centre Pin .. .. .	362/021	—	391/011	—
Spring .. .. .	—	—	122/189	122/189
Spring Washer .. .. .	295/018	224/044	—	—
Centre Stud .. .. .	—	384/004	—	394/004
Seal Washer .. .. .	—	384/013	—	394/020
Filter Pack Assembly .. .. .	—	384/009	—	394/009
Felt Washer .. .. .	—	384/015	—	394/015
Gauze for Felt Pad .. .. .	—	384/006	—	394/006
Felt Pad .. .. .	—	384/005	—	394/005
Gauze Extractor .. .. .	—	384/012	—	394/010
Filter Body .. .. .	—	384/001	—	394/001
Rod Knob and Guide Assembly	—	383/018	—	394/018
Locknut .. .. .	—	244/1408	—	18/053
Nut for Centre Stud .. .. .	—	295/014	—	394/016
Spacing Ring .. .. .	—	—	224/076	—
Cable Nipple .. .. .	308/051	308/051	4/036	4/036
Spring Sheath .. .. .	360/077	360/077	391/023	391/023

★ When ordering Spare Parts please quote complete Carburettor Number found stamped on Carburettor Body at Engine End.

# IceniCAM Information Service



[www.icenicam.org.uk](http://www.icenicam.org.uk)