


# IceniCAM Information Service



SPARKING PLUG (N.7)  
Champion Sparking Plugs Ltd.,  
Feltham, Middlesex.

MAGNETO (MIGEMAG, S90)  
Messrs. Wico-Pacy, Denbigh Road,  
Bletchley, Bucks.

CARBURETTER (335/1)  
Messrs. Amalgamated Carburetters  
Ltd., Perry Barr, Birmingham.

MAGNETO (Type BS9)  
Messrs. H. Miller & Co. Ltd.,  
Aston Brook Street, Birmingham



B.S.A. MOTOR CYCLES LTD.,  
BIRMINGHAM, 11

Telephone: BIRMINGHAM, VICTORIA 2381  
Telegrams and Cables: "SELMOTO BIRMINGHAM."

Service, Spares and Repairs Department  
WAVERLEY WORKS BIRMINGHAM, 10

Telephone: BIRMINGHAM VICTORIA 3711  
Telegrams and Cables: "SELSEV, BIRMINGHAM"

# Catalogue

of



for

# BSA

## Winged Wheel

## Model W1

Prices Effective January, 1960

Plate Ref. No	Part Number	Description	No. per set	Retail Price
94, 95	1-1804	Rear hub spindle washer ... ..	2	£ s. d. 1
96	11-3038	Rear hub spindle nut ... ..	1	3
97	14-3594	Driving piece roller ... ..	5	2
98	62-198	Rear hub complete ... ..	1	1 17 6
99	62-314	Brake cam complete ... ..	1	4 0
100, 101	62-228	Brake shoes complete (steel)... ..	2	15/6 pr.
—	62-474	Brake shoes complete (alloy) ... ..	2	15/6 pr.
102	62-113	Brake cam bush ... ..	1	9
103	62-102	Crankcase complete with outer cover and fittings ... ..	1	4 5 0
104	62-238	Brake cam lever ... ..	1	2 6
105	36-382	Brake cam washer (shakeproof) ... ..	1	1
106	21-5103	Brake cam nut ... ..	1	5
107	62-309	Torque link ... ..	1	9
108	14-3579	Torque clip bolt ... ..	1	2
109	62-246	Torque clip (Roadster) with nut and bolt... ..	1	9
110	1-5954	Torque clip bolt washer (plain) ... ..	1	1
111	62-321	Torque clip (Sports) with nut and bolt ... ..	1	9
112	1-8417	Torque clip bolt nut ... ..	1	3
113	62-106	Cylinder fixing stud ... ..	4	6
114	62-146	Cylinder barrel ... ..	1	1 5 0
115	62-145	Cylinder barrel and crankcase joint washer... ..	1	1
116, 117	62-153	Piston compression ring ... ..	2	2/3 ea.
118	62-151	Piston complete with gudgeon pin, rings, circlips and pegs ... ..	1	16 0
119	62-156	Piston ring retaining peg ... ..	2	1
120	35-4341	Torque link stud ... ..	2	4
121	36-382	Torque link washer (shakeproof) ... ..	2	1
122	21-5103	Torque link nut ... ..	2	5
123	62-385	Rear hub spindle locknut ... ..	1	8
124, 125	1-1804	Rear hub spindle washer ... ..	2	1
126	11-3038	Rear hub spindle nut ... ..	1	3
127	62-115	Crankcase outer cover fixing stud dowel bush	1	3
128	62-108	Crankcase outer cover fixing stud (long) ... ..	2	3
129	62-302	Clutch release lever ... ..	1	1 6
130	62-126	Small end bush ... ..	1	1 0
131	62-154	Gudgeon pin ... ..	1	1 0
132	62-155	Gudgeon pin circlip ... ..	1	3
133	62-219	Silencer baffle ... ..	1	6
134	62-227	Silencer body cover washer ... ..	1	3
135	29-541	Crankcase outer cover fixing nut washer (shakeproof) ... ..	4	1
136	21-5102	Crankcase outer cover fixing nut ... ..	4	2
137	29-541	Magneto fixing screw washer (shakeproof)... ..	2	1
138	62-141	Magneto fixing screw ... ..	2	4
139	62-221	Silencer bolt locknut ... ..	1	2
140	2-1865	Silencer bolt washer ... ..	1	1
141	62-470	Silencer body cover ... ..	1	1 0
142	2-1865	Silencer bolt washer ... ..	1	1
143	21-5364	Silencer body cover bolt ... ..	1	1
144	62-221	Exhaust pipe stud nut ... ..	2	2
145	62-148	Exhaust pipe stud ... ..	2	2
146	—	Exhaust assembly complete N.L.A. ... ..	1	—
147	62-226	Exhaust flange washer ... ..	1	1

Plate Ref. No	Part Number	Description	No. per set	Retail Price
148	62-369	Magneto cable clip ... ..	1	£ s. d. 3
149	67-985	Spark plug cover and suppressor ... ..	1	4 0
150	62-338	Spark plug (14mm.) ... ..	1	5 0
151	62-158	Cylinder head ... ..	1	9 0
152	62-161	Cylinder head securing nut ... ..	4	1
153	62-542	Cylinder head securing plate ... ..	4	2
154	62-207	Inlet pipe joint washer ... ..	1	1
155	62-206	Inlet pipe ... ..	1	2 6
156	62-552	Inlet pipe fixing stud ... ..	2	2
157	62-221	Inlet pipe fixing stud nut ... ..	2	2
158	62-209	Amal carburetter ... ..	1	2 17 6
159	62-283	Throttle cable complete ... ..	1	3 0
160	62-286	Throttle lever ... ..	1	12 6
161	62-353	Brake cable tension spring ... ..	1	3
162	62-277	Brake cable complete ... ..	1	4 0
163	8-2048	Brake lever ... ..	1	7 0
164	21-5407	Petrol tank securing clip bolt ... ..	1	4
165	29-541	Petrol tank securing clip bolt washer (shakeproof) ... ..	1	1
166	62-319	Petrol tank securing clip ... ..	1	9
167	29-541	Petrol tank bar fixing nut washer (shakeproof) ... ..	1	1
168	21-5102	Petrol tank bar fixing nut ... ..	1	2
169	62-274	Clutch lever ... ..	1	7 0
170	62-271	Clutch cable complete ... ..	1	4 0
171	62-262	Flexible petrol pipe ... ..	1	1 6
172	1-6019	Petrol tank stay clip bolt ... ..	6	1
173	62-265	Petrol tank stay clip (outside) ... ..	2	3
174	62-370	Petrol pipe clip ... ..	1	3
175	62-266	Petrol tank stay clip (inside) ... ..	2	3
176	29-3319	Petrol tank stay clip bolt washer (shakeproof)	6	1
177	2-47	Petrol tank stay clip bolt nut ... ..	6	2
178	62-261	Petrol tap ... ..	1	6 0
179	15-792	Petrol tap washer (fibre) ... ..	1	2
180	62-250	Petrol tank and carrier complete (less filler cap) ... ..	1	1 17 6
181	62-259	Petrol tank filler cap and measure ... ..	1	5 0
—	62-378	Petrol tank adaptor set, comprising ... ..	1	} 4/- per set
182	21-5411	Petrol tank securing clip bolt ... ..	7d.	
183	62-319	Petrol tank securing clip ... ..	9d.	
184	1-3241	Petrol tank stay clip bolt ... ..	2d.	
185, 187	62-384	Petrol tank adaptor ... ..	2/0	2
186, 188	27-8560	Petrol tank adaptor washer ... ..	1d.	2
—	62-263	Petrol pipe securing clip with bolt and nut	2	6
—	62-375	Spindle packing washer (crankcase end) ... ..	1	1
—	62-391	Clutch cable complete (tandem fitting) ... ..	1	6 0
—	62-394	Brake cable complete (tandem fitting) ... ..	1	6 0
—	62-397	Throttle cable complete (tandem fitting) ... ..	1	4 0
—	62-538	Hub shell ring (rubber) ... ..	1	5
—	62-541	Magneto fixing screw washer (plain) ... ..	2	1
—	62-564	Clutch and brake cable ferrule ... ..	as reqd.	4
—	62-570	Silencer complete (Burgess) ... ..	1	12 6
—	62-574	Sound absorbent pack (Burgess) ... ..	1	2 0
—	62-575	Silencer locknut (Burgess) ... ..	1	6
—	8-3847	Twist Grip Throttle Control & Dummy Grip		14 0

Plate Ref. No	Part Number	Description	No. per set	Retail Price		
				£	s.	d.
49	62-184	Hub dust cap (large) (no longer fitted) ...	1			3
50	28-43	Crankcase oil filler plug ...	1			7
51	62-138	Crankcase roller ...	13			3
*52	62-111	Roller outer race ...	1	3	0	
53	62-388	Crankcase oil seal ...	1	2	0	
54	62-139	Crankshaft pinion ...	1	2	3	
55	62-242	Clutch release lever pivot ...	1		6	
56	35-701	Clutch release lever split pin ...	2		1	
57	8-1359	Retaining pin washer (steel and alloy shoe) ...	2		1	
58	62-240	Retaining pin spring (steel shoe only) ...	2		3	
*59	2-1096	Retaining pin washer (steel shoe only) ...	2		1	
—	62 563	Retaining pin washer (spring)(alloy shoe only) ...	2		1	
60	35-701	Retaining pin washer split pin (steel shoe only) ...	2		1	
—	62-561	Retaining pin nut (self-locking)(alloy shoe only) ...	2		1	
61	62-236	Brake shoe return spring (steel shoe only) ...	1	1	0	
—	62-479	Brake shoe return spring (alloy shoe only) ...	1		4	
62	62-235	Brake shoe lining (steel and alloy shoe) ...	2	4	6	
63	62-224	Brake shoe lining rivet (steel shoe only) ...	10		1	
—	62-551	Brake shoe lining rivet (alloy shoe only) ...	8		1	
64	35-702	Anchor plate split pin (steel and alloy shoe) ...	2		1	
65	62-451	Anchor plate washer (steel and alloy shoe) ...	2		2	
66	21-5204	Crankshaft pinion nut ...	1		5	
67	62-140	Pinion tab washer ...	1		2	
68	62-290	Hub spindle ...	1	4	0	
69	62-313	Hub spindle oil seal ...	1	2	0	
70	62-456	Hub shell and driven gear ...	1	1	7	6
71	29-925	Hub centre key ...	2		5	
72	62-299	Crankcase inner cover bush (not sold separately) ...	1	1	6	
73	62-110	Crankcase inner cover fixing stud ...	9		2	
74	62-115	Crankcase inner cover dowel bush ...	2		3	
75	29-541	Crankcase inner cover fixing stud washer (shakeproof) ...	9		1	
76	21-5102	Crankcase inner cover fixing stud nut ...	9		2	
77	62-365	Rear wheel spoke (for use with 26"x1½" wheel) (12 gauge) ...	36		1	
—	62-332	Rear wheel spoke (for use with 28"x1½" wheel) (12 gauge) ...	36		1	
78	62-317	Rear wheel rim (26"x1½") ...	1	18	0	
—	62-331	Rear wheel rim (28"x1½") ...	1	19	0	
79	62-351	Roller retainer drive spring ...	1		2	
80	14-3596	Driving piece circlip ...	1		1	
81	62-291	Roller retainer driver ...	1	2	0	
82	14-3575	Ball cage with balls ...	1		7	
83	14-3593	Driving piece ...	1	3	6	
84	62-540	Hub nut lockwasher ...	1		4	
85	62-297	Hub shell nut ...	1	1	6	
86	62-367	Spoke nipple (12 gauge) ...	36		1	
87	62-295	Dust cover ...	1		3	
88	62-374	Sprocket (18T) ...	1	2	0	
89	1-1797	Locking ring ...	1		6	
90	1-4675	¼ diameter steel ball ...	10		1	
91	62-350	Fixed cone ...	1	1	0	
92	14-3614	Oil seal assembly complete ...	1		4	
93	62-376	Cone locking washer ...	1		4	

When ordering replacement parts, the part number should always be quoted thus ensuring that the correct component is supplied.

Plate Ref. No	Part Number	Description.	No. per set	Retail Price		
				£	s.	d.
—	62-316	Wheel with hub and spokes only (26"x1½")	1	3	7	6
—	62-330	Wheel with hub and spokes only (28"x1½")	1	3	10	0
1	1-5991	Cable clip (rubber) ...	3			2
2	62-345	Combined spanner ...	1		2	3
*3	32-9310	Spanner (⅝"x⅜") ...	1		2	3
4	62-458	B.S.A. badge ...	1		2	6
5	62-469	Badge retaining screw ...	4			1
*6	62-296	Crankcase inner cover oil seal ...	1		5	0
*7	62-303	Crankcase inner cover ...	1	1	10	0
*8	86-1256	Clutch shaft bearing ...	1		14	6
9	62-164	Grit protection washer ...	1			3
10	62-176	Clutch operating plate ...	1			3
11	62-163	Clutch shaft ...	1		12	6
12	62-181	Clutch spring housing ...	10			3
13	62-180	Clutch spring ...	10			3
14	62-179	Clutch spring back plate ...	1		2	6
15	62-175	Clutch spring plate ...	1		2	0
16 18	62-173	Clutch driving plate complete with inserts ...	2		3	6
17	62-172	Clutch driven plate (outer) ...	1		2	0
19	62-171	Clutch driven plate (inner) ...	1		2	0
20	62-193	Crankcase inner cover joint washer ...	1			2
21	62-168	Clutch gear wheel complete with bush and inserts ...	1		16	0
22	62-166	Clutch driven back plate ...	1		1	6
23, 25	62-362	Grit protection washer ...	2			3
24	62-165	Clutch bearing circlip ...	1			3
26	86-1256	Clutch shaft bearing ...	1		14	6
27	62-178	Clutch operating rod seal ...	1			3
28	62-177	Clutch operating rod ...	1			4
29	62-142	Magneto complete (Wico-Pacy) ...	1	4	10	0
—	62-486	Magneto complete (Miller) ...	1	4	10	0
30	21-5103	Magneto fixing nut ...	1			5
31	62-307	Drain screw ...	1			3
32	36-382	Magneto fixing nut washer (shakeproof) ...	1			1
*33	62-120	Crankcase outer cover ...	1		17	6
34	62-388	Crankcase outer cover oil seal ...	1		2	0
35	62-358	Roller outer race ...	1		4	0
36	62-138	Crankcase roller ...	13			3
37	62-359	Spacing collar ...	1		1	6
38	62-138	Crankcase roller ...	13			3
39	62-143	Crankshaft key ...	2			4
40	62-123	Flywheel and connecting rod assembly ...	1	2	0	0
41	62-107	Crankcase outer cover fixing stud (short) ...	2			3
42	62-115	Crankcase outer cover fixing stud dowel bush ...	1			3
43	62-117	Oil filler bracket joint washer ...	1			1
44	62-116	Oil filler bracket ...	1		2	0
45	62-118	Oil filler bracket stud ...	2			2
*46	29-3319	Oil filler bracket stud washer (shakeproof) ...	2			1
47	21-5161	Oil filler bracket stud nut ...	2			2
48	62-452	Ball cage with balls ...	1		1	0

\* If 62-120 Crankcase outer cover is required, the Crankcase 62-102 should be returned for matching and selection of suitable spacing collar 62-359.

# BSA

## Winged Wheel

