


BATAVUS

MOPED PARTS PRICE LIST



the quality touch of the expert dutch

BATAVUS

HARGLO LIMITED, 462 Station Road, Dorridge, Solihull.

PARTS PRICE LIST

June 1979

<u>Part No.</u>	<u>Description</u>	<u>Retail</u>	<u>Part No.</u>	<u>Description</u>	<u>Retail</u>
00-006	Bolt	£ 0.10	06-004	Lockring	£ 0.05
00-007	Bolt	0.10	06-005	Lockring	0.05
00-008	Bolt	0.10	06-009	Washer	0.05
00-009	Bolt	0.10	06-010	Spring disc	0.05
00-010	Bolt	0.15	06-011	S/washer	0.05
00-015	Bolt	0.10	06-013	S/disc	0.05
00-024	Bolt	0.10	06-014	Lockring	0.10
00-025	Bolt	0.15	06-021	Cap nut	0.10
00-029	Bolt	0.15	06-023	Lockring	0.15
00-030	Bolt	0.15	06-032	Lockring	0.05
00-032	Bolt	0.15	06-055	Lockring	0.15
00-040	Bolt	0.10	06-065	Nylon ring	0.10
00-046	Bolt	0.10	06-083	Lockring	0.05
00-063	Bolt	0.15	06-085	Washer	0.15
00-080	Bolt	0.20	06-088	Lockring	0.05
00-094	Bolt	0.20	06-089	Washer	0.10
00-121	Bolt	2.25	07-018	Cage nut	0.10
00-133	Stand bolt	0.25	07-023	Speed nut	0.05
00-142	Bolt	0.20	08-001	Cotter	0.35
00-143	Bolt	0.90	08-017	Cotter	Use 08-001
00-144	Bolt	0.45	10-245	Strip	0.55
00-146	Bolt	0.15	10-246	Strip	0.55
00-147	Bolt	0.15	10-251	Strip	0.35
00-149	Bolt	0.30	10-342	Engine bracket	10.00
02-003	Nut	0.35	10-342-01	L/H Engine plate	1.95
02-004	Nut	Use 02-078	10-342-02	R/H Engine plate	2.00
02-005	Nut	Use 02-078	10-342-03	Engine support cradle	3.50
02-012	Nut	0.20	10-344	Exhaust bracket assy	3.50
02-014	Nut	0.15	10-344-01	Exhaust bracket	1.40
02-021	Cap nut	0.10	10-349	No. plate bracket	0.95
02-033	Bolt	0.10	10-353	Exhaust bracket assy	3.75
02-038	Nut	0.10	10-353-01	Exhaust bracket	1.50
02-057	Nut	0.10	10-358	Engine support brkt	12.50
02-059	Ball head nut	0.70	10-358-01	L/H Engine plate	2.75
02-070	Nut	0.10	10-358-02	R/H Engine plate	2.90
02-075	Nut (castellated)	2.75	10-358-03	Engine cradle	3.80
02-077	Nut	0.10	10-369	Seat support	2.50
02-078	Nut	0.10	10-375	Strip	2.00
02-085	Nut	0.60	10-389	Exhaust brkt assy	3.50
03-020	Nut	1.70	10-390	R/mudguard plate	0.90
04-002	Stud	0.10	12-009	Handlebar	4.95
04-003	Stud	0.15	12-186	Stabiliser	2.60
04-009	Stud	0.15	12-194	Handlebar	4.95
04-010	Stud	0.20	12-230	Handlebar	6.75
06-002	Lockering	0.05	12-267	Handlebar	4.95
06-003	Lockring	0.05			

BATAVUS MOPED PARTS - 2 -

<u>Part No.</u>	<u>Description</u>	<u>Retail</u>	<u>Part No.</u>	<u>Description</u>	<u>Retail</u>
12-272	Handlebar	5.95	31-228	Cover shield	3.95
12-297	Handlebar	4.95	31-229	Chainguard	7.20
13-093	Carrier	6.80	33-038-01	Fuel tank	18.50
14-066	L/H Pedal crank	2.95	33-039	Fuel tank	17.50
14-067	R/H Pedal crank	2.95	33-040-01	Fuel tank	30.50
14-073	L/H Pedal crank	2.95	33-042-01	Fuel tank	17.50
14-074	R/H Pedal crank	2.95	33-043	Fuel tank	19.50
14-079	Bearing	1.10			
14-088	R/H Crank	9.50		For 40-089 and 40-091	
16-097	Silencer assembly	12.50		assemblies see 44-229 and 44-230	
16-097-01	Silencer inner	1.95	40-093	Grease nipple	0.20
16-097-02	Silencer rear	3.50	40-098	Freewheel Use 49-019	
16-097-03	Silencer body - Not supplied		40-130	Grease nipple	0.15
16-098	Exhaust pipe	5.50	40-144	Rim	7.50
16-100	Silencer clip	0.75	40-146	Spokes Use 40-173	
16-111	Exhaust pipe	5.50	40-167	Spokes	0.12
16-113	Exhaust shield clamp	0.60	40-168	Rim Use 40-206	
16-114	Exhaust pipe	5.50	40-171	Spokes	0.10
16-116	Silencer assembly	12.50	40-172	Spokes	0.10
16-118	Exhaust pipe	5.50	40-173	Spokes	0.10
16-119	Silencer	16.50	40-178	Rim	6.95
16-119-01	Baffle	2.00	40-180	Spokes	0.10
16-119-02	Silencer end	3.95	40-182	Spokes	0.10
16-119-03	Silencer body -Not supplied		40-184	Spokes	0.10
17-030	L/H Front fender	3.60	40-206	Rim	6.95
17-031	R/H Front fender	3.60	40-207	Rim (28 hole)	6.95
17-032	Carrier fender	2.75	40-209	Spokes	0.10
17-033	Headlamp fender	1.60	40-210	Spokes	0.10
24-073	Lockring	0.10	41-117	Cable nippleholder	0.20
24-103-01	Bracket axle	5.50	41-175	Plastic grip	0.40
30-137	R/mudguard stay	1.20	41-179	Harness plug	0.75
30-183	Fr/mudguard stay	1.20	41-186	Twistgrip assembly	12.95
30-193	R/mudguard S/S	6.75	41-186/A	Rubber	0.95
30-197	R/mudguard	6.75	41-186-01	Bolt	0.20
30-198	F/mudguard stay	1.20	41-186-05	Bolt	0.40
30-221-02	F/mudguard S/S	6.75	41-186-06	Lever	3.75
30-222	R/mudguard S/S Use 30-193		41-188	Fixed grip	0.95
30-224	R/mudguard	10.80	41-204	Decompression lever	2.25
30-228	Front stay	6.00	41-207	Cable adjuster	0.50
30-234	F/mudguard stay	1.20	41-208	Adjuster	0.60
30-235	R/mudguard	6.75	41-244	Twistgrip assembly	5.95
30-238	Fr/mudguard	5.50	41-244-01	Bolt	0.15
30-239	Fr/mudguard	4.25	41-244-02	Lever clamp	3.50
30-242	Fr/mudguard	7.70	41-244-03	Nut	0.05
30-247	R/mudguard	4.50	41-244-04	Washer	0.05
31-182	Chainguard	1.50	41-244-05	Bolt	0.15
31-185	Engine cover shield	6.60	41-244-06	R/H brake lever	1.75
31-202	Plastic extension	2.00	41-244-07	Throttle handle	1.90
31-206	R/H Toolbox	10.40	41-244-08	R/H Plastic grip	0.40
31-207-04	L/H Toolbox cover	4.75	41-244-10	Choke lever	0.95
31-209-01	L/H Cover shield	3.50	41-245	Brake & start lever assembly	5.95
31-210-02	R/H Cover shield	3.50			
31-212-04	R/H Toolbox cover	4.75	41-245-01	Bolt	0.15
31-217	Exhaust shield	6.20	41-245-02	Clamping bracket	3.50
31-218	Cover shield	3.95	41-245-03	Nut	0.05
31-220	Central panel	8.50	41-245-04	Washer	0.04
31-226	L/H Toolbox	10.40	41-245-05	Bolt	0.15
31-227	Cover shield	3.95			

BATAVUS MOPED PARTS - 3 -

<u>Part No.</u>	<u>Description</u>	<u>Retail</u>	<u>Part No.</u>	<u>Description</u>	<u>Retail</u>
41-245-06	L/H Brake lever	£ 1.75	42-252	Headlamp assembly	£ 7.80
41-245-07	Start lever	1.15	42-252-01	Headlamp shell	3.50
41-245-08	Bolt	0.25	42-252-04	Headlamp insert	4.75
41-245-09	Bolt	0.15	42-252-05	Clip	0.20
41-246	Choke cable	0.95	42-252-13	Headlamp fitting	1.70
41-247	Start cable	1.20	42-252-14	Spring	0.15
41-248	Throttle cable	1.25	42-254	Switch	2.50
41-249	R/Brake cable	1.95	42-259	Speedo drive	3.25
41-250	F/Brake cable	1.75	42-272	Flasher unit	3.25
41-269	Clutch cable	1.95	42-273	Turn signal lamp	6.00
41-284	Harness plug Use 41-179		42-275	Turn signal bulb	0.85
41-289	R/Brake cable	1.95	42-276	Rectifier	6.50
41-296	Horn Use 41-413		42-281	Bulb 6v 18/18w	0.75
41-330	Clutch lever assy	6.95	42-282	Speedometer	7.25
41-393	F/brake cable	1.95	42-284	Switch	6.95
41-396	Decomp. cable	1.95	42-285	Switch	3.00
41-400	Throttle cable	1.95	42-286	Tail lamp	8.50
41-401	Choke cable	1.25	42-286-01	Reflector	4.25
41-404	Start cable	1.25	44-005	Footrest	3.00
41-405	Throttle cable Use 41-248		44-016	Spring	0.20
41-406	Choke cable Use 41-246		44-018	Tank cap	1.25
41-407	F/Brake cable Use 41-250		44-021-01	Pedal	1.20
41-408	R/Brake cable Use 41-249		44-021-02	Pedal	1.20
41-409	Start cable Use 41-247		44-050	Tank cap	2.50
41-410	F/Brake cable	2.30	44-113	L/H Crank	2.95
41-411	R/Brake cable	2.40	44-229	Front hub	11.50
41-413	Horn	3.25	44-229-01	Hub shell. Not supplied	
41-414	Horn Use 41-296		44-229-02	Spindle assembly	3.25
41-417	Throttle cable	2.75	44-229-03	Nut	0.20
42-039	Speedo	6.95	44-229-04	Cone	0.60
42-060	Speedo cable	2.00	44-229-05	Dust ring	0.25
42-078	Bulb Use 42-082		44-229-06	Cup	0.60
42-080	Switch Use 42-254		44-229-07	Brake shoe (pair)	2.60
42-082	Bulb	0.35	44-229-08	Brake plate	1.50
42-130	Switch and cable	4.25	44-229-09	Spring	0.20
42-137	Speedo cable	2.00	44-229-10	Cam	1.10
42-138	Speedo drive	3.00	44-229-11	Lever	0.55
42-173	Cable cover (per meter)	0.15	44-230	R/wheel hub assy	15.50
42-179	Plug assembly Use 41-179		44-230-01	R/hub shell Not supplied	
	For 42-180 series use 42-252		44-230-02	Rear spindle assembly	3.50
42-192	Speedo cable	2.50	44-230-03	Nut	0.20
42-212	Mounting cup complete	6.50	44-230-04	Cone	0.60
42-214	Speedo drive	3.80	44-230-05	Dust ring	0.25
42-232	Horn	3.25	44-230-06	Cup	0.60
42-237	Fuse	0.65	44-230-07	Brake shoe assy	2.40
42-238	Rear lamp	2.95	44-230-08	Brake plate	3.00
42-238-01	Reflector	1.10	44-230-09	Spring	0.18
42-238-02	R/lamp housing. Not supplied		44-230-10	Cam	1.10
42-239	Speedo	6.95	44-230-11	Lever	0.55
42-241	Tachometer	28.00	44-230-12	Bolt and nut	0.20
42-245	Headlamp complete	18.00	44-251	Seat pillar	1.35
42-245-01	Headlamp shell	9.95	44-277	Seat pillar	1.35
42-245-02	Headlamp rim	4.25	44-315	Petrol pipe Use 46-315	
42-245-04	Light unit	9.95	44-238	Fuel tap	3.15
42-245-18	Springs (set)	1.00	44-341	Spring	0.35
42-248	Cable cover Use 42-173		44-342	Petrol tap	2.25
42-251	Headlamp bulb	0.65	44-346	Chainwheel 46T	4.25
			44-376	Clip	0.12
			44-379	Chainwheel 50T (special order)	4.25


<u>Part No.</u>	<u>Description</u>	<u>Retail</u>	<u>Part No.</u>	<u>Description</u>	<u>Retail</u>
44-382-01	R/H Pedal Use 44-021-01		45-175	Pedal chain 80L	2.40
44-382-02	L/H Pedal Use 44-021-02		45-196	Cover	1.40
44-393	Front hub assy	22.00	46-001	Rubber buffer	0.15
44-393-01	Front hub shell	Not supplied	46-021	Rubber ring	0.10
44-393-02	Spindle assembly	3.25	46-028	Rubber	0.35
44-393-07	Brake shoes (pr)	3.50	46-029	Rubber sleeve	0.20
44-393-08	Brake plate	2.80	46-050	Rubber ring	0.10
44-393-09	Brake spring	0.35	46-051	Clip	0.40
44-393-10	Brake cam	1.10	46-117	Star ring	0.25
44-393-11	Brake lever	0.75	46-141	Exhaust gasket	0.20
44-393-16	Bearing	2.50	46-158	Dust bellows	0.35
44-400	Rear suspension	7.25	46-162	Rubber buffer	0.20
44-404	Chainwheel	4.25	46-174	Bolt holder	0.30
44-405	Spring	0.35	46-179	Cable grommet	0.15
44-406	Fuel tap	2.40	46-197	Bush	0.45
44-408-02	Spindle assembly	3.50	46-201	Rubber ring Use 46-021.	
44-408-07	Brake shoes (pr)	4.25	46-206	Handlebar clamp set	2.75
44-408-09	Brake spring	0.25	46-208	Flashing strip	3.30
44-408-10	Brake cam	1.10	46-221	Silent bloc	0.85
44-408-11	Brake lever	0.95	46-222	Rubber buffer	0.10
44-408-16	Bearing	2.50	46-223	Rubber sleeve	0.55
44-408-17	Bearing	4.00	46-236	Carb rubber seal	0.15
44-414	Rear suspension	18.00	46-243	Mud flap	0.70
44-425	Headlock assembly	4.25	46-264	Silent bloc	0.85
44-427)			46-279	Dust protector	0.75
44-483)	Lock set	8.50	46-285	Distance bush Use 46-408	
44-441	Fork spring assembly	2.20	46-287	Clip housing	0.40
44-445	Rear hub assy 28 hole	13.50	46-298	Rubber ring	0.10
44-445-01	R/hub shell	Not supplied	46-306	Plastic ring	0.15
44-445-02	Rear spindle assy	3.25	46-309	Spacer tube	0.30
44-446	Front hub assy	11.50	46-310	Spacer tube	0.20
44-446-01	F/hub shell	Not supplied	46-313	Rubbers	0.25
44-446-02	Spindle assy	3.25	46-314	Rubber ring	0.10
44-453	Chainwheel 36T	4.25	46-315	Rubber tube per meter	0.80
44-457	Rear suspension	7.80	46-317	Plastic mat	0.80
44-473	Spring	1.95	46-321-01	Spacer tube	0.65
44-473-01	Plug (screw)	0.60	46-322	Rubber seal	0.40
44-478	Dual seat MK4S	22.00	46-323	Rubber sleeve	0.40
44-499	Chainwheel 48T	4.25	46-324	Bearing plate	1.20
44-504	Petrol tap	2.95	46-329	L/H Plastic mat	0.40
44-505	Dual seat	21.00	46-330	R/H Plastic mat	0.40
44-510	Rear hub assy	32.50	46-331	Spacer tube	0.25
44-510-08	Brake plate	3.30	46-333	Rubber sleeve	0.20
44-511	Chainwheel	4.25	46-335	Bearing	1.50
44-538	Pillion rest	2.00	46-344	Mudflap	3.15
45-009	Chain adjuster Use 45-086		46-346	Instrument bracket	3.00
45-036	Pedal chain 84L	2.40	46-352	Rubber dust ring	2.35
45-066	Pedal chain 82L	2.40	46-353	Shaft seal	1.20
45-066A	Pedal chain link	0.40	46-362	Rubber seal	0.40
45-075	Engine chain 92L	4.95	46-373	Silentbloc	2.90
45-078	Chain adjuster	0.40	46-376	Spring clip	0.15
45-086	Chain adjuster	0.30	46-378	Mats	1.10
45-109	Exhaust gasket	0.20	46-382	Spacer tube	0.50
45-134	Chain	5.95	46-387	Turn signal brkt front	2.50
45-134A	Chain link	0.50	46-392	Engine bracket	4.40
45-167	Engine chain 82L	4.75	46-393	Turn signal brkt rear	3.20
45-174	Engine chain 88L	4.95	46-408	Bush	0.75
45-174A	Engine chain link	0.50	47-003	Balls (per 100)	0.80

Part No.	Description	Retail	Part No.	Description	Retail
47-016	Balls (per 100)	0.95	56-341	* Frame (Compact)	31.50
47-017	Ball head set	3.95	56-381	* Frame (MK4S)	55.00
47-017-01	Cone	0.75	56-386-01*	Rear wheel assy	42.50
47-017-02	Cup	0.75	56-414	Front fork assy Use 56-224	
47-017-03	Cup	0.75	56-414-03	Fork legs C/w crown plate	Use 56-224-03
47-017-04	Cone	0.60			
47-043	Ball head set	2.75	56-421	* Frame (Bronco)	35.00
47-043-01	Cone	0.75	56-441	* Frame (HS50)	38.00
47-043-02	Bearing shell	1.00	56-452	* Fork (rear)	20.00
47-043-03	Bearing shell	1.00	56-456	* Rear wheel assy	22.00
47-043-04	Adjuster cone	0.90	86-006	Toolbox	1.50
47-065	Crown plate	1.95	86-012	Toolkit	1.50
47-093	Ring	0.25			
47-097-107	Expander	1.20	<u>ENGINE PARTS</u>		
47-114	Steering head set	4.25	480125	Gasket set	0.95
47-115	Balls (per 100)	1.00	480180	Crankcase Use 485180	
47-119	Crown plate Use 47-065		480181	Gasket	0.15
48-116	Rim band (Go-Go)	0.35	480182	Grommet	0.20
48-139	Rim band (Compact)	0.45	480183	Grommet	0.15
49-019	Freewheel	2.25	480325	Little end bush	0.55
49-020	Freewheel	2.25	480381	* Crankshaft	23.50
49-124	Auto chain tensioner	1.75	480382	Conrod set	17.50
54-064	Seat	8.95	480501	Gudgeon pin	2.00
54-071	Seat Go-Go	9.25	480502	Piston ring Std	0.95
54-071-01	Plate	0.30	480511	Piston ring 1st O/S	1.20
54-086	Seat Compact	13.50	480512	Piston ring 2nd O/S	1.20
54-088	Seat Bronco	14.50	480580	Piston complete Std	12.50
56-012	* Rear fork	15.00	480581	Piston complete 1st O/S	13.50
56-017	Centre stand	5.60	480582	Piston cmpte 2nd O/S	13.50
56-053	Footbrake lever	8.20	480682	Cylinder base gasket	0.15
56-087	Stand Use 56-137		480683	Exhaust gasket Use 46-141	
56-132	* Rear fork	18.00	480690	Cylinder	19.75
56-135	* Front wheel assy	18.50	480880	Clutch housing	
56-136	* Rear wheel assy	21.00		c/w bearing	6.95
56-137	Centre stand	4.50	480881	Clutch hub complete	3.95
56-141	* Frame V	35.00	480882	Endplate	1.10
56-165	* Front wheel assy	32.50	480883	Pressure spring	0.15
56-211	* Frame VA	32.50	480886	Clutch spring	2.00
56-224	Front fork assy	29.50	480887	Saucer spring	0.25
56-224-01	R/H Fork leg	4.50	480889	Friction plate	2.50
56-224-02	L/H fork leg	4.60	480890	Locking plate	0.50
56-224-03	Fork legs c/w crownplate	10.50	480891	V Belt	3.50
56-224-04	Stabiliser	0.95	480980	Starter leaf spring	1.25
56-264	Front fork assy	38.00	480981	Support plate	0.35
56-264-01	Fork top c/w crownplate	12.50	481092	Sprocket 12T	1.85
56-224-02	Crown plate	2.75	481093	Sprocket 13T	1.85
56-264-04	L/H Slider	6.00	481505	Tab nut	1.50
56-264-05	R/H Slider	6.00	481590	* Pulley 12T	12.50
56-264-06	L/H Headlamp bracket	2.95	481591	Cover	0.25
56-264-07	R/H Headlamp bracket	2.95	481598	* Pulley 13T	12.50
56-264-10	Stabiliser	1.80	481713	Intake silencer	1.95
56-265	* Front wheel	19.00	481721	Screw top	1.25
56-331	* Fork assembly	75.00	481722	Valve spring	0.30
56-331-01	Fork yoke bottom	8.50	481724	Clamp screw	0.20
56-331-02	Fork yoke top	7.65	481731	Jet holder	1.20
56-331-04	Fork leg	15.00	481732	Air filter	1.95
56-331-05	Fork leg	15.00	481733	Rubber ring	0.25
56-331-06	Headlamp bracket	3.40	481735	Silencer clip	0.40
56-331-08	Fork tube & spring	13.50	481736	Float	1.75
56-331-16	Fork clamp	2.10	481737	Cover gasket	0.15

<u>Part No.</u>	<u>Description</u>	<u>Retail</u>	<u>Part No.</u>	<u>Description</u>	<u>Retail</u>
481738	Float chamber cover	2.00	843500	Washer	0.05
481739	Screw	0.15	843600	Washer	0.05
481740	Banjo	0.75	844510	Washer	0.05
481741	Filter	0.35	846600	Spring washer	0.05
481742	Banjo bolt	0.70	847400	Washer	0.05
481743	Choke valve	0.45	847600	Washer	0.05
481744	Spring	0.35	848011	Washer	0.05
481745	Screw	0.05	No. 58	Jet	0.60
481746	Adjusting screw	0.35	No. 56	Jet	0.60
481747	Spring	0.20			
481751	Adjusting nipple	0.45	<u>DECALS (Stickers)</u>		
481752	Tab nut	0.25	72-807	Go-Go Tank (R/H)	0.80
481783	Membrane	2.75	72-808	Go-Go Tank (L/H)	0.80
481784	Inlet gasket	0.10	72-933	HS50 Tank (R/H)	0.75
481785	Induction pipe	1.25	72-934	HS50 Tank (L/H)	0.75
481786	Shield	0.60	72-955	Cover shield (R/H)	0.60
481789	Carburettor	17.50	72-956	Cover shield (L/H)	0.60
481793	Intake tube	0.30	72-966	Fuel tap	0.20
481797	Washer	0.10	72-995	MK4S Tank (L/H)	0.80
481821	Stator	POA	72-996	MK4S Tank (R/H)	0.80
481822	Rotor	POA	72-1005	Bronco tank (R/H)	0.75
481825	H.T. Coil	8.95	72-1006	Bronco tank (L/H)	0.75
481826	Contact set	2.15	72-1018	MK4S Sidecover (L/H)	0.80
481829	Lighting Coil	6.50	72-1019	MK4S Sidecover (R/H)	0.80
481829/A	" " small	3.00	72-1031	HS50 Sidepanel (R/H)	0.75
481840	Condenser	2.50	72-1032	HS50 Sidepanel (L/H)	0.75
481887	Spark plug W240TI	0.70		Go-Go 2 Tank (R/H)	0.75
481887/A	" " W260TI	0.70		Go-Go 2 Tank (L/H)	0.75
481890	Suppressor	1.50		Go-Go 2 Cover shield R/H	0.60
485180	Crankcase	19.50		Go-Go 2 Cover shield L/H	0.60
485690	Cylinder	19.75	480201	Engine cover	0.25
485695	Cylinder head	9.50		HS50 cover shield	
486723	Throttle slide	1.10		top strip	0.20
540292	Cover spring (per 20)	2.00		Compact Tank (L/H)	0.80
540898	Pressure plate	1.25		Compact Tank (R/H)	0.80
810081	Ball bearing	2.95		Touch-up paint matching	
813081	Needle bearing	2.75		moped colours (per tin)	0.75
813086	Needle bearing	1.95			
816180	Oil seal	0.75	<u>SERVICE TOOLS</u>		
816181	Oil seal	1.20			<u>NET</u>
816480	Gas & Oil seal	1.40	485001	Ballrace fitting dolly	1.00
820500	Bolt	0.10	485002	Flywheel extractor	2.25
820502	Bolt	0.10	485003	Little end bush press	2.25
820520	Bolt	0.10	485004	Timing adjuster	1.75
820603	Bolt	0.10	485005	Clutch hub steady	3.00
820700	Bolt	0.15	485006	Fitting sleeve for	
820701	Bolt	0.15		clutch bearing	0.60
823400	Screw	0.05	485007	Adaptor	0.50
823422	Screw	0.25	485009	Ballrace extractor	7.50
823506	Crankcase screw	0.15	485010	Flywheel steady	4.00
827500	Nut	0.05		Grease gun	1.95
827600	Nut	0.05	485011	Oil seal tool	1.35
827700	Nut	0.05	485012	Oil seal tool	1.50
828000	Flywheel nut	0.20			
828010	Locknut	0.10			
829680	Cylinder stud	0.45			
830000	Flywheel key	0.15			
840010	Tab washer	0.10			
841512	Circlip	0.25			
841520	Circlip	0.10			

* 25% only, trade discount.

IceniCAM Information Service



www.icenicam.org.uk