



IceniCAM Information Service



www.icenicam.org.uk



Synchromatic Drive Spare Parts List

This list shows only the components special to the Synchromatic Drive. For spares not shown on this list see the 'Power Pak Spares List' at your dealers.

PLEASE QUOTE PART No. ENGINE No. AND DESCRIPTION

PART No.	DESCRIPTION	Price s. d.	PART No.	DESCRIPTION	Price s. d.
1	Cylinder Head.....	18 0	38	Thrust Bearing Plain Washer.....	3 0
2	Piston.....	12 7	39	Thrust Bearing (complete).....	5 0
3	Gudgeon Pin.....	2 0	40	Thrust Bearing Grease Cover.....	6
4	Connecting Rod.....	10 9	41	Crankshaft.....	56 0
5	Crankcase.....	46 6	42	Crankshaft Locking Nut.....	1 6
6	Crankcase Oilseal.....	2 9	43	Washer for 42.....	3
7	Driving Roller.....	15 9	44	Stator Plate Securing Screw (S/D Type).....	2
8	Driving Roller Inner Bearing.....	15 0	45	Synchromatic Drive Transfer.....	1 0
9	Driving Roller Outer Bearing.....	15 0	46	Twist-Grip Control Complete.....	16 0
10	Driving Roller Oilseal.....	2 9	47	Twist-Grip Control Rubber.....	1 6
11	Driving Roller Circlip.....	8	48	Twist-Grip Control Steel Tube and Quadrant.....	4 6
12	Driving Roller Large Distance Collar.....	6 6	49	Twist-Grip Control Body—Upper section.....	4 0
13	Driving Roller Small Distance Collar.....	3 0	50	Twist-Grip Control Body—Lower section.....	4 0
14	Clutch Housing.....	16 3	53	Twist-Grip Control Body Clamping Screw.....	2
15	Clutch Housing Securing Screw.....	2	54	Twist-Grip Control Body Grub Screw.....	8
16	Clutch Housing Bearing.....	10 6	55	Twist-Grip Control Body Adjusting Screw.....	5
17	Clutch Housing Oilseal.....	2 7	56	Twist-Grip Control Body Adjusting Spring.....	5
18	Clutch Housing Inner Washer.....	6	57	Twist-Grip Control Body Adjusting Ball.....	2
19	Clutch Housing Grease Nipple.....		58	Twist-Grip Control Body Curved Distance Piece.....	3
20	Fork.....	1 6	59	S.D. Type Petrol Tank.....	56 0
21	Fork Carrier Spindle.....	2 4	60	S.D. Type Carburettor Throttle Slide Spring.....	4
22	Split Pin for 21.....	1	61	S.D. Type Carburettor Throttle Slide.....	4 1
23	Clutch Lever.....	1 8	62	S.D. Type Engaging Lever.....	16 0
24	Nut for 23.....	2	63	Anti-Splash Guards (Set) with screws and nuts.....	3 0
25	Washer for 23.....	1	65	Power Pak Gauge Set.....	3 0
26	Clutch Retainer.....	15 6	66	Power Pak Cycle Pennant (inc. Fittings).....	1 6
27	Clutch Drive Plate.....	18 6	67	S.D. Type Throttle Control Cable Assembly.....	
28	Locating Key for 27.....	3	Type A. (For 'Single Gent' Cycle).....	2 6	
29	Clutch Centre Plate complete with.....		Type B. (For 'Lady's Cycle' or 'Double Gent Tandem').....	3 6	
30	Clutch Composition Plate.....	9 0	Type C. (For 'Lady Back Tandem').....	4 6	
31	Clutch Outer Plate.....	2 2	68	S.D. Type Clutch Control Cable Assembly.....	
32	Clutch Circlip.....	8	Type A. (For 'Single Gent' Cycle).....	3 6	
33	Clutch Spring.....	5	Type B. (For 'Lady's Cycle' or 'Double Gent Tandem').....	4 6	
34	Spring Cup.....	6	Type C. (For 'Lady Back Tandem').....	5 6	
35	Dust Cover.....	3 2	ASS/1/SD	S.D. Type Mounting L. Bracket/Tray Assembly.....	27 6
36	Gasket for 35.....	6	ASS/2/SD	S.D. Type Extended L. Bracket/Tray Assembly.....	27 6
37	Felt Washer for 35.....	4	ASS/7/SD	Driving Roller Assembly.....	52 0

Your local Power Pak dealer can obtain all of these parts for you. If you are in any difficulty or do not understand this list, please contact us.

POWER PAK SERVICE STATION, Shrewsbury Mews, Chepstow Road, Bayswater, London, W.2.
Telephone: BAYswater 6894.