


Catalogue number C0552  
Price code —  
Date 10 June 2005

IceniCAM Information Service

## CYCLEMASTER CONTROLS



**PLEASE** read your instruction Book carefully.

P.T.O.

## To START your

# Cyclemaster

THE MAGIC WHEEL THAT WINGS YOUR HEEL



1. Close choke.
2. Open petrol tap.
3. Lift clutch lever.
4. Set throttle control to midway position.
5. Pedal until cycle is well under way.
6. Release clutch handle; as clutch engages, engine will start.
7. Once engine is running, open choke as soon as possible.

### IMPORTANT HINTS

1. Do not hinder the performance of your engine by riding with the back-pedalling brake on. Keep pedals horizontal and avoid any back pressure except when actually using brake.
2. Avoid sudden jerks, and always ride as smoothly as possible. When starting with the engine ticking over (as in traffic) give a little pedal assistance.
3. In your own interests, always use the recommended grades and quantities of oil as in your instruction book.

P.T.O.